


If your AirCycler STAT does not respond to button pushes it is because the button contacts are dirty and need to be cleaned.

First: remove the circuit board from the housing by pushing the plastic latches out of the way with one hand while pushing on one of the buttons with the other hand. The circuit board will pop out of the cover housing.



Next: using a pencil eraser, clean the three silver contact pads.



Replace the circuit board in the cover housing. Replace the unit on the base and now you should see the buttons respond like they were new.